

# Montageanleitung Reserveradeinsatz für Mercedes G-Modelle mit 7,5x18 ET 63 Felge Art.-Nr. 80-380-10

1. Reserverad abnehmen und originalen Reserveradhalter gegen den mitgelieferten Träger austauschen
2. Reserverad montieren
3. Unterlegscheibe auf die zentrale Gewindestange aufschieben. Reserveradeinsatz einsetzen, ausrichten und mit zentraler Handmutter und zweiter Unterlegscheibe befestigen. Gegebenenfalls müssen zur korrekten Ausrichtung die drei Gummipuffer des Einsatzes eingestellt werden. Beispiel: sitzt der Einsatz trotz angezogener Handmutter zu weit unten, müssen die unteren Gummipuffer weit herausgedreht werden etc.

## Installation instruction Spare-wheel inset for Mercedes G models with 7,5x18 ET 63 rim art. no.80-380-10

1. Take the spare wheel off and change the original carrier for the new one delivered
2. Mount the spare wheel back to the car
3. Put one of the two washers M10 on the central thread-rod. Apply the spare wheel storage box, align and tighten it with the Handfemalescrew and the second washer. If needed use the three rubber-buffers for further adjustment



radeinsatz\_2sprachig.pdf